

Intermediate Maintenance Checklist – Boxster/S (981) (2013)

Required Maintenance and Lubrication Service

* **Oil Change** Every 10,000 miles (15,000 km) or 1 year. **See Below Check Box.**

- Intermediate Maintenance** (Labor Operation 03 14 00 ..) See Technical Manual
After 20,000, 60,000, 100,000, 140,000 miles etc. / 30,000, 90,000, 150,000, 210,000 km etc.
Note: If the mileage for scheduled maintenance is not reached, intermediate maintenance must be performed no later than after 2, 6, 10..... years.

The terms 'check' and 'inspection' include all necessary subsequent work such as adjusting, readjusting, correcting and topping off, but do not include repairing, replacing and reconditioning parts or assemblies.

Electrics

- Diagnosis system: Read out fault memory; reset maintenance interval
- Windshield wiper/washer system, headlight washer: Check function and nozzle adjustment
- Horn: Check operation
- Tires: Check tire pressure (TPM)
- Batteries and ventilation hoses: Check condition
- Electrical equipment as well as indicator and warning lights: Check operation

Inside of Vehicle

- Pollen filter: Replace filter element

Front Luggage Compartment

- Pollen filter: Replace pre-filter element
- Check front lid lock and safety hook of the front lid for secure seating and function properly
- Windshield wiper/washer system, headlight washer: Check fluid level and antifreeze protection level
- Check firewall body drains for debris

Outside of Vehicle

- Check wiper blades
- Vehicle lighting: Check operation
- All headlights: Check adjustment
- Radiators and air intakes: Visual inspection for exterior debris and blockage

Under the Vehicle

- Drain engine oil and change oil filter
- Tires: Check condition
- Brake system: Visual inspection of the brake pads and brake discs for signs of wear (without removing wheels)
- Brake hoses and lines: Visual inspection for damage, correct routing and corrosion Check brake fluid level
- Axle shafts: Visual inspection of the dust boots for leaks & signs of damage

Rear Luggage Compartment

- Fill engine oil (Every 10,000 miles/15,000 km, see separate Oil Change Sheet, PNA 000 162 LC)
- Coolant: Check level and antifreeze protection level
- Check firewall body drains for debris

Additional Maintenance – Replace Spark Plugs (Labor Operation 03 81 00 ..)

- Replace spark plugs: every 40,000 miles / 60,000 km or 4 years

Additional Maintenance - Drive Belt Labor operation 03 60 00 ..

- Check drive belt at 40,000 miles (60,000 km) or every 4 years
- Check drive belt at 100,000 miles (150,000 km) or every 10 years
- Check drive belt at 160,000 miles (240,000 km) or every 16 years

Additional Maintenance every 60,000 miles / 90,000 km or 6 years (Labor Operation 03 83 00 ..)

- Replace drive belt

Additional Maintenance every 80,000 miles / 120,000 km or 4 years (Labor Operation 03 85 00 ..)

- Ancillary unit mounts and chassis: visual inspection of all rubber mountings and boots for damage

Additional Maintenance every 120,000 miles / 180,000 km or 12 years (Labor Operation 03 88 00 ..)

- Manual transmission: change oil
- PDK transmission: change oil
- PDK transmission: change clutch oil

Additional Maintenance every 2 years (Labor Operation 03 51 00 ..)

Change brake fluid (use only Original Porsche Brake Fluid)

Additional Maintenance every 4 years (Labor Operation 03 52 00 ..)

Replace tire sealant

Inspection Performed - Technician Signature: _____

Road Test Check

Remote control, front seats, foot brake and electric parking brake (also operating travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM, PASM & Sport switches, sports exhaust system, door mirror fold-in function, heater, air-conditioning system and instruments: Check operation

Oils, fluids: Visual inspection for leaks

Road Test Performed - Technician Signature: _____

Customer Name: _____

Date: ____/____/____

VIN: WP _____

Mileage (check one) **Miles** **Kilometers:** _____

Dealer Name: _____

Dealer Code: _____

Repair Order #: _____

Technician Name: _____

Technician Signature: _____